


## Toast 2 pcs



### eikon® e2s

01:00

This recipe is available for:

- eikon® e2s SP (1000W)
- eikon® e1s

Accessories:

e2s Flat Cook Plate PSB3108 Ovens purchased before January 2019, DB0739 Ovens purchased from January 2019.

P  
R  
O  
F  
I  
L  
E

- 275 °C
- Ambient
- 2 Slices
- From Scratch

Stage 1

- 00:25
- 100 %
- 10 %

Stage 2

Turn the Toast Over

- 00:35
- 100 %
- 10 %

R  
E  
C  
I  
P  
E

#### Ingredients

2 slice White Bread

#### 1. Food Preparation

Place them direct on the plate.

#### 2. Cooking Instruction

Cook as per oven profile.

#### 3. Food Serving Instruction

Remove the cooked food from the plate and serve.