



Toast 2 pcs



eikon® e2s

 01:00




This recipe is available for:

- eikon® e2s SP (1000W)
- eikon® e1s




Accessories:

e2s Flat Cook Plate PSB3108 Ovens purchased before January 2019, DB0739 Ovens purchased from January 2019.

P
R
O
F
I
L
E




-  275 °C
-  Ambient
-  2 Slices
-  From Scratch

Stage 1

-  00:25
-  100 %
-  10 %

Stage 2

Turn the Toast Over

-  00:35
-  100 %
-  10 %

R
E
C
I
P
E

Ingredients

- 2 slice White Bread

1. Food Preparation

Place them direct on the plate.

2. Cooking Instruction

Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the plate and serve.