

Reheat Cornish Pasty



e1s

01:30

This recipe is available for:

- eikon® e1s
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)

Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P R O F I L



260 °C



Chilled 4°C



1 Piece



Prebaked

Stage 1

00:50



. 100 %

Stage 2

00:40

₩ 75 %

. 0 %

Ingredients

1 pcs

Cornish Pasty

1. Food Preparation Place it on the tray.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.

F C I F