

Garlic Bread



eikon® e3

02:00

This recipe is available for:

- eikon® e4
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4s
- eikon® e1s
- eikon® e5

Accessories:

e3 Flat Turn-table Plate 40H0347
e3 Non-stick Cooking Liner 40H0190

P
R
O
F
I
L
E

- 275 °C
- Ambient
- 1 Slice
- From Scratch

Stage 1

- 02:00
- High
- 0 %

R
E
C
I
P
E

Ingredients

1-4 slice

Garlic Bread

1. Food Preparation

Place them on the liner.

2. Cooking Instruction

Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the liner and serve.