Garlic Bread



e1s

01:00

This recipe is available for:

- eikon® e4
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4s
- eikon® e1s
- eikon® e5

Accessories:

e1s/e2s Non-stick Cooking Liner 32Z4088 (Natural), 32Z4096 (Green)



260 °C



Ambient



1 Slice

From Scratch

Stage 1

01:00

% 100 %

. 20 %

Ingredients

1-3 slice

Garlic Bread

- 1. Food Preparation Place them on the liner.
- 2. Cooking Instruction Cook as per oven profile.
- 3. Food Serving Instruction Remove the cooked food from the liner and serve.