

### Chicken Breast without skin



# e2s

## **02:15**

#### This recipe is available for:

- eikon® e4
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e5
- eikon® e1s

#### Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P R O F I L E



275 °C



Crimeu 4



1 Piece

From Raw

Stage 1

02:15



**.** 60 %

Ingredients

140 g

Chicken Breast

- 1. Food Preparation Place it on the tray.
- 2. Cooking Instruction Cook as per oven profile.
- 3. Food Serving Instruction
  Remove the cooked food from the tray and serve.