

Reheat Jacket Potato 1 pce



e2s

01:00

This recipe is available for:

- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e4s
- eikon® e5
- eikon® e1s

Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P R O F I L E



275 °C

Chilled 4°C



1 Piece



Precooked

Stage 1

01:00

% 50 %

. 100 %

Ingredients

1 pcs

Potato

1. Food Preparation Place it on the tray.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction
Remove the cooked food from the tray and serve.

F E