

## Reheat Jacket Potatoes 2 pcs



## e2s

**02:00** 

## This recipe is available for:

- eikon® e4s
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e5
- eikon® e1s

## Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)



275 °C



Chilled 4°C



2 Pieces



Precooked

Stage 1

01:00



Stage 2

Turn the Potatoes

Over

01:00



Ingredients

2 pcs

Potatoes

1. Food Preparation Place them on the tray.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.