

Reheat Jacket Potatoes 2 pcs



eikon® e4

01:50

This recipe is available for:

- eikon® e4s
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e5
- eikon® e1s

Accessories:

e3/e4/e4s Non-stick Tray ideal for baking/roasting 40H0230

P
R
O
F
I
L
E

- 275 °C
- Chilled 4°C
- 2 Portions
- Precooked

Stage 1

- 00:55
- 40 %
- 100 %

Stage 2

Turn the Potatoes Over

- 00:55
- 40 %
- 100 %

R
E
C
I
P
E

Ingredients

2 pcs

Potatoes

1. Food Preparation

Place them on the tray.

2. Cooking Instruction

Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.