

## Reheat Jacket Potatoes 2 pcs



## eikon e4

**01:50** 

## This recipe is available for:

- eikon® e4s
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e5
- eikon® e1s

## Accessories:

e3/e4/e4s Non-stick Tray ideal for baking/roasting 40H0230



275 °C



Chilled 4°C



2 Portions



Precooked

Stage 1

00:55

₩ 40 %

Stage 2 Turn the Potatoes

Over





**.** 100 %

Ingredients

2 pcs

Potatoes

1. Food Preparation Place them on the tray.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.