

Reheat Bread Pakora 3 pcs







This recipe is available for:

- eikon® e2s HP (2000W)
- eikon® e1s

Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)







Chilled 4°C



3 Pieces



Prebaked

Stage 1





. 100 %

Ingredients

3 pcs

Bread Pakora

1. Food Preparation Place them on the tray.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.