

Rusti Pani





This recipe is available for:

- eikon® e4s
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4

Accessories:

e1s/e2s Non-stick Cooking Liner 32Z4088 (Natural), 32Z4096 (Green)



275 °C



Frozen -18°C



1 Piece





Partially Baked





₩ 80 %

. 100 %

Ingredients

1 pcs

Rusti Pani

1. Food Preparation

Place it on the liner.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the liner and serve.