Reheat Quiche



e1s

01:50

This recipe is available for:

• eikon® e1s

Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

R O F I L



260 °C



Chilled 4°C



1 Piece



Prebaked

Stage 1





. 100 %

Ingredients

180 g

Quiche

1. Food Preparation Place it on the tray.

2. Cooking Instruction Cook as per oven profile.

3. Food Serving Instruction
Remove the cooked food from the tray and serve.