## Reheat Cheese&Potato Ink Bread





00:25

This recipe is available for:

• eikon® e1s

## Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P R O F I L



260 °C



Ambient



1 Piece



Prebaked

Stage 1





**.** 75 %

## Ingredients

pcs R

Reheat Cheese&Potato Ink Bread

- 1. Food Preparation Place it on the tray.
- Cooking InstructionCook as per oven profile.
- 3. Food Serving Instruction
  Remove the cooked food from the tray and serve.