

## Reheat Puff Pastry Sausage Roll





**0**0:30

This recipe is available for:

• eikon® e1s

## Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

P R O F I L



260 °C





1 Piece



Prebaked

Stage 1

**(**9 00:30

₩ 50 %

**.** 100 %

Ingredients

130 g

Puff Pastry Sausage Roll

- 1. Food Preparation Place it on the tray.
- Cooking InstructionCook as per oven profile.
- 3. Food Serving Instruction
  Remove the cooked food from the tray and serve.