

Garlic Bread







This recipe is available for:

- eikon® e4
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4s
- eikon® e1s
- eikon® e5

Accessories:

e5 Enamel Baking/Roasting Tray P40C1423 (Black), P40C1151 (Green), P40C1157 (Blue)



250 °C



Ambient



1 Slice From Scratch Stage 1







<u></u> 0 %

Ingredients

1-8 slice

Garlic Bread

- 1. Food Preparation Place them on the hot tray.
- 2. Cooking Instruction Cook as per oven profile.
- 3. Food Serving Instruction Remove the cooked food from the tray and serve.