

## Reheat Jacket Potato 1 pce



**eikon® e5**

**01:30**

This recipe is available for:

- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e4s
- eikon® e5
- eikon® e1s

Accessories:

e5 Enamel Baking/Roasting Tray P40C1423 (Black), P40C1151 (Green), P40C1157 (Blue)

P  
R  
O  
F  
I  
L  
E

- 250 °C
- Chilled 4°C
- 1 Piece
- Precooked

Stage 1

- 01:30
- High
- 100 %

R  
E  
C  
I  
P  
E

### Ingredients

1 pcs

Potato

### 1. Food Preparation

Place it on the tray.

### 2. Cooking Instruction

Cook as per oven profile.

### 3. Food Serving Instruction

Remove the cooked food from the tray and serve.