


Reheat Bagels



eikon® e1s

 00:50


This recipe is available for:

- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e4s
- eikon® e1s
- eikon® e3
- eikon® e4




Accessories:

e1s Flat Cook Plate DC0322

P
R
O
F
I
L
E

-  260 °C
-  Ambient
-  1 Piece
-  Prebaked

Stage 1

-  00:50
-  100 %
-  10 %

R
E
C
I
P
E

Ingredients

1-2 pcs

Bagels

1. Food Preparation

Place them direct on the plate.

2. Cooking Instruction

Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the plate and serve.