

Reheat Jacket Potatoes 2 pcs



eikon® e1s

02:00

This recipe is available for:

- eikon® e4s
- eikon® e2s SP (1000W)
- eikon® e2s HP (2000W)
- eikon® e3
- eikon® e4
- eikon® e5
- eikon® e1s

Accessories:

e1s/e2s Full Size Cooking Tray 32Z4080 (Black),
32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

PRO
FI
LE

- 260 °C
- Chilled 4°C
- 2 Pieces
- Precooked

Stage 1

- 01:00
- 70 %
- 100 %

Stage 2

Turn the Potatoes
Over

- 01:00
- 70 %
- 100 %

RE
CI
PE

Ingredients

2 pcs

Potatoes

1. Food Preparation

Place them on the tray.

2. Cooking Instruction

Cook as per oven profile.

3. Food Serving Instruction

Remove the cooked food from the tray and serve.