

www.merrychef.com

## **Teacake Halves**





Accessories: e1s/e2s Full Size Cooking Tray 32Z4080 (Black), 32Z4100 (Red), 32Z4093 (Green), 32Z4101 (Blue)

	0°C	Stage 1	
O F	P Ambient	00:35	
	2 Pieces	🛞 100 %	
	Prebaked	۵ %	
	Ingredients		1. Food Preparation
	2-4 pcs Teaca	ake Halves	Lay out evenly on the tray.
			2. Cooking Instruction
			Cook as per oven profile.
			3. Food Serving Instruction
			Remove the cooked food from the tray and serve.

Note: Information emanating from Welbilt is given after exercise of all reasonable care and skills in its compilation, preparation and issue, but is provided without liability in its application and use. All cooking settings are guides only. Adjust cooking settings to allow for differing product weights and start temperatures. Always ensure that food save core temperature has been achieved prior to service.